

GET STARTED WITH YOUR NEW LED WIRE

- 1 Insert fresh batteries in the battery box. The light will automatically turn ON in the **6 hrs timer function** (it will be ON for 6 hrs, after that it will turn OFF, and after 18 hrs it will automatically turn ON again).
- 2 Press the button on the battery box once for the **ON function** (without timer).
- 3 Press the button on the battery box the 2nd time, and the light will turn **OFF**.
- 4 Press the button on the battery box the 3rd time, and the light will turn ON and work at the **6 hrs timer function** again (cycled).
- 5 Control the light with the **Deluxe Homeart remote** (not included). (ON/OFF & several timer functions + 4-levels dimming function).

FAULT DETECTION

If the product does not light up, please check that the product is turned on.

DISPOSAL OF PRODUCT

Electric / electronic equipment contains materials, components and substances that may be harmful for human health as well as for the environment, if not handled correctly. Electric / electronics equipment is marked with a crossed out wheelee bin and means proper disposal of the product is required.

As a consumer you can help protect the environment and ensure that the product is recycled in accordance with legislation by disposing of the product properly.

IMPORTANT SAFETY INSTRUCTIONS

- Mount and dismount the light decoration properly and carefully, as knocks and jolts may cause damage to the product or reduce the lifetime of the LEDs.
- When taking down and repacking the light decoration, the product must be clean and dry.
- Never put the light decoration in a sealed plastic bag, as condensation may occur and the product will be damaged by moisture.
- Cable and LEDs for this light decoration cannot be replaced. If damaged, the product must be discarded.
- The light decoration is not a toy and should be placed out of reach of small children.
- Do not mix old and new batteries.
- Exhausted batteries are to be removed from the product.

CONTACT

kundeservice@deluxehomeart.com
+45 71 99 19 09

DELUXE HOMELIGHT

Plantinvej 7D
DK-6000 Kolding



Scan the QR code for more product labeling info

KOM IGANG MED AT BRUGE DIN LED WIRE

1 Isæt nye batterier i batterikassen. Lyset tændes automatisk (**ON**) i **6 timers timerfunktionen** (det vil være tændt i 6 timer, derefter slukkes det (OFF), og efter 18 timer tændes det automatisk igen)

2 Tryk 1 gang på knappen på batteriboksen for **ON**-funktionen (uden timer).

3 Tryk 2 gange og lyset slukkes (**OFF**).

4 Tryk 3 gange for **ON**-funktionen med **6 timers timerfunktionen** igen.

5 Betjen LED wiren med en **Deluxe Homeart remote** (ikke inkluderet). (ON/OFF & forskellige timerfunktioner + 4-trins lysdæmperfunktion).

FEJLFINDING

Er der ingen lys i dekorationen, kontrolleres det om produktet er tændt på batterikassen.

AFSKAFFELSE AF PRODUKT

Elektrisk / elektronisk udstyr indeholder materialer, komponenter og stoffer, der kan være skadelige for menneskers sundhed og for miljøet, hvis affaldet ikke håndteres korrekt. Elektrisk / elektronisk udstyr er mærket med den overkrydsede skraldespand. Den symboliserer, at elektrisk /elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt. Som slutbruger er det

vigtigt, at du afleverer dine udtjente produkter til de ordninger, der er etableret. På denne måde er du med til at sikre, at materialerne genanvendes i overensstemmelse med lovgivningen og ikke unødigt belaster miljøet. Alle kommuner har etableret indsamlingsordninger, hvor kasseret elektrisk/ elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer og andre indsamlingssteder eller blive afhentet direkte fra husholdningerne. Nærmere information kan fås hos kommunens tekniske forvaltning.

VIGTIGE SIKKERHEDSINSTRUKTIONER

- Montér lysdekorationen på forsvarlig vis da slag, stød og unødigt overlast kan medføre beskadigelse af produktet og/eller ned-sættelse af produktets levetid.
- Ved nedtagning/pakning af lysdekorationen skal produktet være rent og tørt.
- Læg aldrig lysdekorationen i en forsegleet plastikpose, da der kan opstå kondens og produktet vil blive beskadiget af fugt.
- Ledning og LED'er til denne dekoration kan ikke udskiftes. Såfremt disse beskadiges, skal produktet kasseres.
- Lysdekorationen er ikke legetøj og placeres uden for børns rækkevidde.
- Bland ikke gamle og nye batterier.
- Opbrugte batterier skal fjernes fra produktet.